



INSTRUCTION MANUAL

OIL FILLED RADIATOR

Model No.: OFR Flat Fin





Dear Customer,

Congratulations!

You are now the proud owner of Usha Oil Filled Radiator (Model No.: OFR Flat Fin)

Innovatively designed, using only the highest quality material and components, your Usha Oil Filled Radiator (Model No.: OFR Flat Fin) is designed for years of trouble free performance.

Please read this Instruction Manual carefully before using and keep it cautiously after reading for future reference.

Best Wishes

IMPORTANT PRECAUTIONS

1. Read the instructions carefully before use and save them for future reference
2. When the heater starts work, it allows some slight sound.
3. Never turn the heater upside-down during operation
4. Always disconnect the heater from the main supply when not in use and when cleaning
5. Always disconnect the heater from the main supply when move it
6. Never plug in the same main supply with other electric ties, or it may lead to a fire.
7. Do not leave the heater "On" unattended
8. Never cover the heater as this may lead to risk of fire.
9. Never put the wire on the heater when in use
10. Never let castors or other objects press on the wire when in use.
11. Never touch the heater when in use
12. Keep the heater a distance of at least 50cm from the wall and keep out at least 100cm from above
13. Close supervision is required when any appliance is used near or by children
14. Never allow the cord to touch wet or hot surfaces, become twisted or be within the reach of children
15. Do not use outdoors
16. Do not place on or near a hot gas or electric burner
17. Never use the appliance with a damaged cord or plug after the appliance has malfunctioned or been damaged in any way.
18. Never attempt to open any part or dismantle the controls. Responsibility for failure can not be accepted if these instructions have been ignored.
19. Do not use the appliance for anything other than its intended use.
20. This appliance is intended for household use only.
21. Regulations concerning the disposal of the oil when scraping the appliance have to be followed.
22. Any repairs that need to be done to the heater must be referred to an Usha authorised service centre.

23. The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
24. Young children should be supervised to ensure that they do not play with the appliance.
25. If the supply cord is damaged, it must be replaced by the Usha authorised service centre.
26. The heater must not be located immediately below a socket-outlet.
27. This heater is filled with a precise quantity of special oil. Repairs requiring opening of the oil container are only to be made by the Usha authorised service centre, if there is an oil leakage. Regulations concerning the disposal of the oil when scrapping the appliance have to be followed.

PARTS DESCRIPTION

1. Handle
2. Thermostat control
3. Power setting switch
4. Oil filled panel
5. Wheel base
6. Castors



ASSEMBLY

Remove the heater and all the accessories from the carton.

1. Turn the heater upside down
2. Position the wheel base to the place where a label indicates
3. Turn the heater the right way up

HUMIDIFIER

1. Put the 2 pipes to the holes inside the humidifier
2. Position the humidifier to the middle side of the heater

Warning: Plug the heater 3 minutes later after the product is turned to the right way up

OPERATING YOUR OIL FILLED RADIATOR

Place the heater on the floor, and make sure it is at least 50cm away from the wall and any other objects such as furniture, Curtains or plants.

(Make sure the power supply used corresponds to the one on the rating label)

With the thermostat control in the “O” position and the power setting switch in the “OFF” position, plug the heater into the main power supply.

OPERATION

1. Room temperature can be adjusted using the thermostat. Simply turn the thermostat switch clockwise to increase the heat, and anti-clockwise to decrease the temperature, until reach your desired temperature.
2. Switch the heater to the following power setting:
 - Push switch one (Above) for 800W
 - Push switch two (Below) for 1200W
 - Push switch one & two (Above& Below) for 2000W
3. The power switch lights up when activated
4. Turning the thermostat control will increase the “set ” temperature
5. Turning the thermostat control anti-clockwise will decrease the “set” temperature
6. Do not cover the heater at any time during operation. There is a risk of fire if the heater is covered.



7. Once you have finished using your heater, turn the power switches off, and the thermostat control to the “O” position, and unplug from the main supply.

CLEANING YOUR OIL FILLED RADIATOR

- 1 Always disconnect the heater from the mains supply before cleaning.
- 2 Clean the outside of the heater by wiping with a damp cloth and buff with a dry cloth.
- 3 DO NOT use waxes or polishes as these may react with the heater and cause discoloration.

STORING YOUR OIL FILLED RADIATOR

- 1 Save the box for off season storage.
- 2 Clean the heater following the cleaning instructions above.
- 3 Remove the wheel base assemblies.
- 4 Place the heater, and wheel assemblies in the original box, and store in a cool and dry place.
- 5 If you choose to store your heater fully assembled, to be sure to cover it to protect it from dust.

WARRANTY CARD

This Oil Filled Radiator is warranted for one year against all manufacturing defects from the date of sale. In the event of any complaint, please contact your nearest Company Service Centre or call at our Toll Free no: 1800-1033-111.

This Warranty is valid only when...

1. The Oil Filled Radiator has not been opened or tempered with, by any unauthorized person.
2. The warranty card or cash memo duly signed by the authorized dealer are presented with the complaint.
3. The Oil Filled Radiator has been installed, used and maintained in accordance with the instructional manual.

This Warranty does not apply for...

1. Damages due to chipping, peeling, plating and denting.
2. Breakage or damage to components made out of Bakelite, Urea, ABS, SAN and such plastic, materials, rubber parts and cord.
3. Normal wear and tear of parts.
4. Damage resulting from accidents, mishandling or negligence on part of the customer.

Liability for consequential loss or damage is neither accepted nor implied.

S.NO: _____

CASH MEMO _____ DATE: _____

DEALER'S NAME AND ADDRESS: _____

OWNER'S NAME & ADDRESS: _____

Email: usha_care@ushainternational.com

Website: www.ushainternational.com

 <http://www.facebook.com/ushainternational>

USHA care

Toll free

1800-1033-111

USHA INTERNATIONAL LTD.

Plot No.15, Institutional Area, Sector 32, Gurgaon - 122 001 (Haryana) Tel : +91-124-4583100, Fax : +91-124-4583200

E-mail : corporate@ushainternational.com Website : www.ushainternational.com

Regd. Office : Surya Kiran Building, 19 Kasturba Gandhi Marg, New Delhi (India) Tel : +91 11 23318114 Fax : +91 11 23318118

ISO 9001: 2008
Certified Company



Fans • Sewing Machines • Home Appliances • Engines & Pumpsets • Electrical Motors & Pumps • Water Coolers & Dispensers
• Inverters • Cook Tops, Hobs & Hoods • Auto Components

USHA

® Registered Trademark and Copyright of USHA INTERNATIONAL LTD.



® Registered Trademark of USHA INTERNATIONAL LTD.