



# **INSTRUCTION MANUAL**

**USHA COCE** 

—— Toll free—— 1800-1033-111

Email: usha\_care@ushainternational.com f http://www.facebook.com/ushainternational



E-mail: corporate@ushainternational.com Website: www.usha.com 

Fans • Sewing Machines • Home Appliances • Engines & Pumpsets• Electrical Motors & Pumps • Water Coolers & Dispensers

• Inverters • Cook Tops, Hobs & Hoods • Auto Components





**JUICER** Model No- JC 3240





Dear Customer,

Congratulations!

You are now the proud owner of Usha Juicer.

Innovatively designed, using only the highest quality material and components, your Usha Juicer is designed for years of trouble free performance.

Please read this Instruction Manual carefully before using and keep it cautiously after reading for future reference.

**Best Wishes** 

### WARRANTY CARD

This appliance is warranted for 2 year on product against all manufacturing defects from the date of sale. In the event of any complaint, please contact Usha Care at Toll Free No. 1800 1033 111.

### The warranty is valid only when:

- 1) The appliance has been installed, used and maintained in accordance with the instruction manual.
- 2) The warranty card and cash memo duly signed by the authorized dealer are presented with the complaint.
- 3) The appliance has not been opened or tampered with, by any unauthorized person.

#### This warranty does not apply for:

- 1) Damages due to chipping, peeling, plating and denting.
- Breakage or damage to components made out of Bakelite, Urea, ABS, SAN and such plastic materials, rubber parts and cord.
- 3) Normal wear and tear of parts.
- Damage resulting from accidents, mishandling or negligence on part of the customer.

Liability for consequential loss or damage is neither accepted nor implied.

OWNER'S NAME & ADDRESS:





#### **OPERATING TIME**

This machine is designed with button switches of O grading, I grading, II grading (O for stop, I for weak grading, II for strong grading). For juicing, select strong grading, for operating time, after operating for 1min, stop for 1min, then use again. After the above operation is performed for three times, stop for 15 min, do not operate until the motor is cooled, in this way, service life of this machine will be prolonged, the machine will serve you more efficiently.

#### **CLEANING AND MAINTENANCE**

- 1. This machine shall be often used, so as to keep the motor dry and clean.
- 2. If not using for a long time, please store this machine at a dry and well-ventilated place so as to prevent the motor from being damped and going moldy.
- 3. Don't wash the main machine. When cleaning, only wipe with wet cloth. Other components may be washed directly with water, such as pushing bar, cover, middle seat, residue cup, juice nozzle cover.

#### **TECHNICAL SPECIFICATIONS**

Voltage 220-240V AC

Frequency 50Hz Wattage 400W


#### **IMPORTANT PRECAUTIONS**

- 1. This machine should not be used by unresponsive or psychopathic person and children. Children should be overseen, so it can be testified that they are not playing with it.
- 2. Before using, put this machine on a stable and even table board, operate according to the above methods.
- 3. Before juicing, first confirm juicing net and rotor clutched in position, and no hard contact between juicing net cutter and transparent cover. Put the transparent cover on, fasten tight the handle, then turn on the machine.
- 4. Before being used, the motor works in running-in phase, there may be slight peculiar smell and spark, this is normal, after the motor works for some period, the above phenomenon will disappear.
- 5. During juicing, make sure there is not too full juice and residue in the middle seat and residue cup, if too full, please cut off power supply, clean up, then use again.
- 6. During using, do not open the cup cover. In case power supply is on, do not put hand or any ware into the mixing cup or feed port, otherwise, harmful accident may occur or this machine may be damaged.
- 7. In order to prolong service life of this machine, over-temperature protective device is mounted in the motor. If the motor works for a long time or overloaded, when over warning temperature, power supply will automatically cut off. After the motor stops, pull out plug of power supply, wait for the motor to cool (about for 30 min), use again.
- 8. During operating, please do not leave, never let children operate this machine.
- 9. When this machine works in mixing, mincing or grinding conditions, no-loaded or over loaded work is strictly prohibited.
- 10. After operation, do not pour the food out until pull out the plug of power supply.
- 11. Cutters are very sharp, in order to avoid danger, when cleaning a cutter, please put the cutter under water tap for washing, do not wash it with hand.
- 12. This machine must not be used for others beyond regulated purposes.
- 13. In case of damaged power supply cord, in order to avoid danger, replacement must be performed by the company authorized service centre or its service representative. In case of fault, do not disassemble the machine by yourself, please contact Usha authorized service centre.



## USHA

#### MAIN COMPONENTS NAME



#### **MAIN FEATURES**

- 1. For the juicer with large diameter, entire apple or pear can be put in for juicing, no cutting apart needed, easy and guick.
- 2. Design is fine, simple, and beautiful, with combined structure, easy to operate and clean.
- 3. High speed electric motor with overheating protection is adopted, high efficiency, time saving and high service life of the motor.
- 4. Safety lock unit for switching is specially designed, in order to make sure safety and reliability in use.

#### ATTENTION BEFORE USING

- 1. This machine is set with safety unit, when the handle does not fasten the cover or the cutter seat is not fastened, the motor cannot turn, so as to ensure safety for the user.
- 2. When disassembling or assembling the juicer, press the upper of feed port of the cover with your hand, then force the handle to slide in or out of cover slot
- 3. When disassembling juicing net, first remove the cover and residue barrel, then turn the middle ring up to 30 degrees by holding juicing nozzle with your hand, and take up, the juicing net will automatically leave the rotor.
- 4. In order to avoid damage, before using, first check power supply for compliance with rated voltage.
- 5. Clean all parts able to disassemble (refer to the section of "maintenance and cleaning").
- 6. When assembling, please carefully read the diagram of "name and position of main components".
- 7. Please carefully read the "attentions" before using.

#### **OPERATION**

- Before using, please confirm the button switch of the main machine in stop state, in this way, in case assembly is not completed, starting the main machine can be avoided, so unnecessary damage for persons or property avoided.
- 2. Before juicing, first confirm juicing net and rotor clutched in position, and no hard contact between juicing net cutter and transparent cover. Put the transparent cover on, put the handle into the cover slot, and then turn on the machine.
- 3. For using, assemble according to the diagram of "name and position of main components". Turn on power supply, press switch to let the machine run no-load for 5 sec. Put prepared vegetable or fruit into feed port of the juicer, press with the pushing bar, evenly, hard and slowly, juice of the vegetable or fruit can be found, original, fresh, good for health.

Note: when pressing food with the pushing bar, force shall be even or indirect, pressing force shall not be more than 1 kg, no too sudden force, otherwise, juicing effect will be reduced.